

allomatic.net



# ALL-O-MATIC

## MAGNA Q

### BARRIER ARM OPERATOR MANUAL



# MAGNA Q

## BARRIER ARM OPERATOR



Reduces Costs   Enhances Safety   Minimizes Downtime & Repairs

EACH INCLUDE: ARM ATTACHMENT   15' ARM   DISABLE SENSOR

04-2026



The widest selection of **AC & DC Gate Operators** for all your residential and commercial installations.

SLIDERS | SWINGERS | OVERHEADS | BARRIER ARM OPERATORS

allomatic.net



# TABLE OF CONTENTS

## **SAFETY AND INTRODUCTION**

- Safety Instructions ..... 1–2
- UL 325 Class Types ..... 3
- Operator Specifications ..... 4

## **INSTALLATION**

- Operator Dimensions & Concrete Pad ..... 5
- Arm Opening Direction & Travel Adjustment ..... 6
- Arm Attachment Bracket Installation ..... 7
- Arm Disable Sensor Installation ..... 8
- Lane Layout & Operational Configurations ..... 9–12
- AMS (Access Management System)  
& Trap/Sally port Setup ..... 13-15
- LED Strip & Edge Sensor Installation ..... 16
- AC Power Electrical Wiring Connections ..... 17

## **BOARD FEATURES**

- DIP-Switch Functions ..... 18
- Auto Close Timer & Receiver Wiring ..... 19
- Arm Force Adjustment ..... 20
- Primary/Secondary Setup & Wiring ..... 21
- Auxiliary Relay & Leaf Delay Setting ..... 22

## **ACCESSORY INSTALLATION**

- Entrapment Protection Installation ..... 23–25
- Accessory Wiring ..... 26–27
- Solar Panel Wiring ..... 28–29
- LED Diagnostics ..... 30
- Technical Troubleshooting ..... 31
- AUX Inputs Programming ..... 32
- LCD Display Settings & Diagnostics ..... 33–36

## **MANUAL RELEASE INSTRUCTIONS**

- Manual Operation ..... 37

## **ACCESSORIES & PARTS BREAKDOWN**

- Blowout Drawing ..... See Website

## **WARRANTY AND CUSTOMER RECORD**

- Warranty & Customer Record ..... 38–39

# IMPORTANT SAFETY INSTRUCTIONS

## **WARNING**

TO REDUCE THE RISK OF **INJURY**:

**READ AND FOLLOW ALL INSTALLATION INSTRUCTIONS. DO NOT START INSTALLATION UNTIL YOU HAVE READ AND UNDERSTOOD THESE DIRECTIONS. IF THERE IS SOMETHING YOU DO NOT UNDERSTAND, PLEASE CALL US.**

**NEVER** let children operate or play with barrier arm controls.

Locate the control station and make sure it is (a) within sight of the barrier arm and (b) at a minimum height of 5 feet so small children cannot reach it.

Install the enclosed entrapment warning signs next to the control station and in a prominent location.

For operators equipped with a manual release, instruct the end user on the correct operation of the manual release. Use the manual release only when the barrier arm is not moving. It is advised to turn off the power.

Always keep people and objects away from the barrier arm. No one should cross the path of a moving barrier arm.

The barrier arm operator must be tested. The barrier arm must reverse on contact with a rigid object, or stop when an object activates the non-contact sensor(s). Always re-test the operator after adjusting the limits and/or force. Failure to adjust and re-test the barrier arm operator properly may cause severe injury.

Keep barrier arm operator properly maintained. Have a qualified service technician make repairs to gate hardware and make proper adjustments to barrier arm operator.

This barrier arm entrance/exit is for vehicles only. Pedestrians must use a separate entrance.

There is nothing on a barrier arm operator that can be easily repaired or adjusted without a great deal of experience. Call a qualified service technician who knows your barrier arm operator.

## SAVE THESE INSTRUCTIONS

# IMPORTANT SAFETY INSTRUCTIONS (CONTINUED)

## INSTALL THE BARRIER ARM OPERATOR ONLY AFTER YOU HAVE READ THE FOLLOWING

### BEFORE GATE OPERATOR INSTALLATION

- Confirm that the barrier arm operator being installed is appropriate for the application.
- Confirm that all appropriate safety features and safety accessory devices are being installed, including all entrapment protection devices.
- Repair or replace worn or damaged gate hardware before installing the gate operator.

### BARRIER ARM OPERATOR INSTALLATION

- Operator must be disconnected from the power source before attempting any installation of accessories.
- Install barrier arm operator according to the installation instructions in this manual.
- Install a proper electrical ground to the barrier arm operator.
- Controls intended for user activation must be located at least 6 feet away from any moving part of the barrier arm, and where the user is prevented from reaching over, under, around, or through the barrier arm to operate the controls.
- Outdoor or easily accessible controls shall have a security feature to prevent unauthorized use.
- The stop and/or reset button must be located in the line of sight of the barrier arm. Activation of the operator reset control shall not cause the operator to move.
- Install a minimum of 2 warning signs, one on each side of the barrier arm where they are easily visible.
- Take pictures of the installation.
- Test all safety features for proper function before placing the automatic vehicular barrier arm in operation.

### MAINTENANCE

- Train owners/users on the basic functions and safety features of the barrier arm system, including how to turn off the power and operate the manual disconnect feature.
- Leave safety instructions, product literature, installation manual, and maintenance manual with the owner or end user.
- Explain to the owner or end user the importance of routine service and operator testing on a monthly basis.

# UL 325 CLASS TYPES AND OBSTRUCTION SENSING SYSTEMS

Each class must have (2) monitored entrapment protection devices in each entrapment zone to sense and react to obstructions within 2 seconds.

All-O-Matic's gate operators conform to the most rigid Class One.

## UL 325 CLASS TYPES

### **CLASS ONE: RESIDENTIAL**

- A vehicular gate operator intended for use in garages or parking areas associated with a residence of one to four single families.

### **CLASS TWO: COMMERCIAL OR GENERAL PUBLIC ACCESS**

- A vehicular gate operator intended for use at a commercial location or building, such as a multi-family housing unit (five or more single family units), hotel, garages, retail stores, or other buildings accessible by or servicing the general public.

### **CLASS THREE: INDUSTRIAL OR LIMITED ACCESS**

- A vehicular gate operator intended for use at an industrial location or building, such as a factory, loading dock area, or other locations not accessible by or intended to service the general public.

### **CLASS FOUR: RESTRICTED ACCESS**

- A vehicular gate operator intended for use at a guarded industrial location or building, such as airport security areas or other restricted access locations not servicing the general public and where unauthorized access is prevented via supervision by security personnel.

## THE SIX TYPES OF OBSTRUCTION SENSING SYSTEMS

### **TYPE A:**

- Inherent entrapment protection system. This system must sense and initiate the reverse of the gate within 2 seconds of contact with a solid object.

### **TYPE B1:**

- Non-contact sensor (photoelectric sensor or equivalent). This system shall, upon sensing an obstruction in the direction of the gate travel, reverse the gate within a maximum of 2 seconds.

### **TYPE B2:**

- Contact sensor (edge device or equivalent). This system shall, upon sensing an obstruction in the direction of the gate travel, initiate the reversal of the gate within a maximum of 2 seconds.

### **TYPE C:**

- Inherent force limiting, inherent adjustable clutch, or pressure relief valve.

### **TYPE D:**

- Actuating device requiring continuous pressure to maintain opening or closing motion of the gate.

# OPERATOR SPECIFICATIONS

	MAGNA Q 19	MAGNA Q 26
<b>Standard Arm Length</b>	15'-7"	26'
<b>Arm Extension Option</b>	4'-1" (for 19'-8" max length)	N/A
<b>Warranty</b>	10 year aluminum cabinet 3 years electrical and mechanical parts	10 years aluminum cabinet 3 years electrical and mechanical parts
<b>Motor</b>	24 VDC brushless with integrated gearbox	24 VDC brushless with integrated gearbox
<b>Arm Speed</b>	2.5 to 4.5 seconds per 90° (varies depending on arm length)	4.5 to 8 seconds per 90° (varies depending on arm length)
<b>Power Options</b>	115 VAC 50/60Hz, single phase - 4 amps 230 VAC 50/60Hz, single phase - 2 amp 24 VDC solar panel - up to 80 watts	115 VAC 50/60Hz single phase - 4.5 amps 230 VAC 50/60Hz single phase - 2.5 amps 24 VDC solar panel up to 80 watts
<b>Duty Cycle</b>	Continuous	Continuous
<b>Temperature Range</b>	-20° to 150°	-20° to 150°
<b>Gearbox Type</b>	Helical Bevel and Spur Gear	Helical Bevel and Spur Gear
<b>Width X Length X Height</b>	11" W X 14" L X 42" H	11" W X 14" L X 42" H
<b>Shipping Weight</b>	120 lbs.	125 lbs.
<b>Manual Release</b>	Crank Spindle	Crank Spindle
<b>Battery Backup</b>	Two 7Ahr Batteries	Two 7Ahr Batteries
<b>Arm Protection</b>	Breakaway Standard	41B22X7/8
<b>Breaker Requirement</b>	20 amp dedicated	20 amp dedicated
<b>UL Classes</b>	II, III & IV	II, III & IV

# OPERATOR DIMENSIONS AND CONCRETE PAD

## Concrete Pad Installation Guidelines

### 1. Verify Local Codes

Check with local building authorities to determine required depth for the concrete pad.

### 2. Pad Height

Ensure the top of the concrete pad is **4 inches above ground level**.

### 3. Anchoring the Operator

Use **four (4) 3" anchor bolts** to securely fasten the operator to the concrete pad.


### 4. Conduit Placement

Route all conduits to the **center of the pad**. Refer to the dimensions below for the available area.


### 5. Operator Orientation

Mount the operator so the arm faces the direction of lane traffic flow.

*(See the illustration at the bottom left of this page for reference.)*



# ARM OPENING DIRECTION AND TRAVEL ADJUSTMENT



## Setting the Barrier Arm Opening Direction

Use the **OPEN L/R dip switch (#8)** to configure the barrier arm operator's opening direction.

### Determining Opening Direction:


The opening direction is determined from the perspective of **standing behind the barrier operator and facing the control board**.

- Indicator LEDs on the control board will show the gate's movement direction during operation.

### Dip Switch Settings:

- OPEN L/R Switch OFF** → Left-hand opening
- OPEN L/R Switch ON** → Right-hand opening

After setting the direction Dip-switch, run a cycle (open and close). After the initial cycle the next step is to attach the arm attachment bracket. See Arm Attachment page.



## Limit Switch Adjustment Instructions

**To Adjust the Limit Switches:** Set limit switches after arm leveling adjustment has been completed.

- Make sure CLOSE LIMIT cam is left in factory setting.
- Verify that the 3 pivot points in the motor articulating mechanism aligned as shown in images below with green dotted line. Depending on the direction setting, mechanism will be in different position. see left and right configurations.
- Only adjust the Open Limit Switch cam as follows:
  - Rotate **toward** the limit switch to **decrease** travel.
  - Rotate **away** from the limit switch to **increase** travel.



- Re-secure the limit cam** by tightening screw using a phillips screwdriver.
- Once the limits are correctly set, move the arm to the **closed position**.

### Final Step – Learn Slow Down:

- Press and release the **"RESET"** button on the circuit board.
- Run the arm through **one uninterrupted cycle** (full open and full close) to calibrate the slow down function.
- This process automatically adjusts the speed to reliably and smoothly move the arm up and down.

**IMPORTANT:** To ensure a 90° arm opening, the articulating motor mechanism must be positioned as shown in the left- and right-hand illustrations. The three pivot points must be aligned correctly in closed position for the arm to open fully to 90°.


**POSITIVE STOPS:** The articulating crank arm must not contact the positive stops. Maintain at least 1/4 in. of clearance between the articulating crank arm and the positive stop.



# ARM ATTACHMENT BRACKET INSTALLATION

## ARM ATTACHMENT BRACKET INSTALLATION PROCEDURE:


1. Set the direction in which the arm will open. Refer to the "ARM Opening Direction" section for dip-switch configurations that control motor direction.
2. After setting the dip-switch, run a cycle (open/close) to position the motor on the CLOSE limit switch. Confirm that the CLOSE-LIMIT LED is ON. Also, verify that the operator shaft rotates properly when running in both the OPEN and CLOSE directions.
3. Align the arm attachment bracket with the motor shaft. Position the bracket so the breakaway clip inserts face the traffic lane, and ensure the top of the bracket is as level as possible. (It does not need to be perfectly level, as final adjustments can be made later via motor calibration.)
4. Align the washer flange with the holes in the arm attachment bracket. Use eight (8) socket head bolts to attach the bracket to the motor shaft, and tighten all bolts securely. Finally, install the hex bolt into the center of the motor shaft and ensure it is also fully tightened.



### Important:

It is crucial that the arm attachment bracket is installed in the correct direction.

**If the bracket is mounted backwards or reversed, the breakaway function will not work properly, which can lead to equipment damage or safety issues.**




## LEVELING ARM PROCEDURE

After the arm attachment bracket has been installed, mount the arm. Run one cycle (open/close) with the arm mounted and follow these steps to level the arm while it is in the lowered position and the board's CLOSE-LIMIT LED is ON:

1. Loosen the four (4) anti-slip set screws, followed by the anti-slip bolts (on anti-slip clamp).
2. If the output shaft clamp bolt (located behind anti-slip clamp) is not already loose, loosen it as well.
3. Manually position the arm so it is level, and hold it in that position.
4. While keeping the arm level, tighten the anti-slip socket head bolts first, then the anti-slip set screws.
5. Finally, tighten the output shaft clamp bolt to secure the shaft and maintain the arm's level position.

**NOTE:** The anti-slip set screws only need to be hand-tightened. Do not apply torque.



# ARM DISABLE SENSOR INSTALLATION

## Arm Disable Sensor Installation

Follow these steps to properly install the **Arm Disable Sensor** once the arm attachment bracket has been mounted to the motor shaft in the correct opening direction:

### 1. Mount the Sensor

- Align the sensor's mounting holes with the pre-drilled holes on the **top side** of the arm mounting bracket.
- Ensure the sensor is positioned **inside** bracket, with the **wire harness facing toward the pivot bolt**.  
(See illustration below for reference.)

### 2. Secure the Sensor

- Use the provided sensor mounting hardware (**square nuts, split lock washers, and screws**) to firmly secure the sensor to the bracket.

### 3. Route the Wire Harness

- Route the sensor's wire harness **toward the pivot bolt**, then back into the operator cabinet through the **pre-installed grommet**.
- Important:** Use the grommet located on the **back side**, closest to the arm pivot bolt.

### 4. Connect to the Board


- Inside the operator cabinet, continue routing the wire harness to the **board terminal block** at the **bottom left corner** of the board.
- Make the following wire connections: (from factory it may come with a jumper to COMMON, remove jumper when wiring sensor).
  - Black wire** → Connect to the **COMMON** terminal (located below the FP\_DISABLE screw).
  - Red wire** → Connect directly to the **FP\_DISABLE** terminal screw.

### 5. Verify Sensor Alignment and Operation

- Ensure the **magnet** mounted at the top of the arm **aligns properly** with the sensor (center of magnet must be at edge of sensor).
- Verify that when the arm is in its secured (normal) position:
  - The **FP\_DISABLE LED** on the board **turns off**, indicating correct sensor operation.

### Notes:

- Secure all wiring neatly to prevent interference with moving parts.



### Important:

It is crucial that the arm attachment bracket is installed in the correct direction.

**If the bracket is mounted backwards or reversed, the breakaway function will not operate properly, which can lead to equipment damage or safety issues.**

# ENTRY LANE ONLY LOOP LAYOUT

## Entry Lane Only — Wiring and Board Configuration

### 1. Down Loop (Safety Loop) Setup

- Install a **PRIME-VD1** or **PRIME-VD2** plug-in loop detector in the **Safety Loop** slot of the **LPR-2** rack.
- Safety Input Modes:**  
The safety input can operate in two ways:
  - Down Loop Only Function (see note)**
    - Turn the **ONE-PASS** dip-switch **ON** and **OSC OFF**.
  - Down and Safety/Reverse Function**
    - Turn the **OSC** dip-switch **ON** & **ONE-PASS OFF**.
  - Down and Pause Function**
    - Turn the **OSC** & **ONE-PASS** dip-switches **ON**.
    - If the loop is activated while the arm is moving down, the arm will pause and wait for the vehicle to back away before resuming the down cycle. If an open command is received, the arm will return to the up position.
  - Safety/Reverse only Function**
    - Turn the **OSC** & **ONE-PASS** dip-switches **OFF**.
    - Auto close timer** setup is required for this option.
- Detector Setting:**  
On the **PRIME-VD1** or **PRIME VD2** detector, configure the output as **Normally Closed (N.C.)**. (follow detector manual for this process)

### 2. Access Control Device Wiring

- Connect the access control device to the **COMMON** and **OPEN** terminal screws on the control board.

### 3. (Optional) Arming Loop Setup


- To use an arming loop with the access control device:
  - Install a **PRIME-VD1** or **PRIME-VD2** plug-in loop detector in the **Phantom Loop** slot of the **LPR-2** rack.
  - On the **PRIME-VD1** or **PRIME-VD2** detector, configure the output as **Normally Open (N.O.)**. (follow detector manual for this process)
  - Enable the Arming Loop:
    - Access the **LCD Settings Menu**.
    - Find and **enable the ARMING** loop setting.
    - See LCD display instructions page for more details.

### Note:

Once Arming loop is enabled, the control board will only initiate an open cycle if a command from the access control device is received **while a vehicle is detected** by the arming loop. If no vehicle is detected, access control commands will be ignored.

### Important:

When Down Loop is configured as Down Loop only, a Down Loop activation while arm is traveling down, will not interrupt the down/close cycle. The arm will continue to complete the down/close cycle.



# EXIT LANE ONLY LOOP LAYOUT

## EXIT Lane Only — Wiring and Board Configuration

### 1. Down Loop (Safety Loop) Setup

- Install a **PRIME-VD1** or **PRIME-VD2** plug-in loop detector in the **Safety Loop** slot of the **LPR-2** rack.
- Safety Input Modes:**  
The safety input can operate in two ways:
  - Down Loop Only Function (see note)**
    - Turn the **ONE-PASS** dip-switch **ON** & **OSC** **OFF**.
  - Down and Safety/Reverse Function**
    - Turn the **OSC** dip-switch **ON** & **ONE-PASS** **OFF**.
  - Down and Pause Function**
    - Turn the **OSC** & **ONE-PASS** dip-switches **ON**.
    - If the loop is activated while the arm is moving down, the arm will pause and wait for the vehicle to back away before resuming the down cycle. If an open command is received, the arm will return to the up position..
  - Safety/Reverse Only Function**
    - Turn the **OSC** & **ONE-PASS** dip-switches **OFF**.
    - Auto close timer** setup is required for this option.


### Detector Setting:

On the **PRIME-VD1** or **PRIME-VD2** detector, configure the output as **Normally Closed (N.C.)**. (follow detector manual for this process)

### 2. Exit Loop Setup

- Install a **PRIME-VD1** or **PRIME-VD2** plug-in loop detector in the **EXIT Loop** slot of the **LPR-2** rack.
- Detector Setting:**  
On the **PRIME-VD1** or **PRIME-VD2** detector, configure the output as **Normally Open (N.O.)**. (follow detector manual for this process)

**NOTE:** When Down Loop is configured as Down Loop only, a Down Loop activation while arm is traveling down, will not interrupt the down/close cycle. The arm will continue to complete the down/close cycle.



# BI-DIRECTIONAL TRAFFIC LANE

## BI-DIRECTIONAL Traffic Lane — Wiring and Board Configuration

### 1. Down Loop (Safety Loop) Setup

Install a **PRIME-VD1** or **PRIME-VD1** plug-in loop detector in the **Safety Loop** slot of the **LPR-2** rack.

#### Safety Input Modes:

The safety input can operate in two ways:

#### a. Down Loop Only Function

- o Turn the **ONE-PASS** dip-switch **ON** & **OSC** **OFF**.

#### b. Down and Safety/Reverse Function

- o Turn the **OSC** dip-switch **ON** & **ONE-PASS** **OFF**.

#### c. Down and Pause Function

- o Turn the **OSC** & **ONE-PASS** dip-switches **ON**.
- o If the loop is activated while the arm is moving down, the arm pauses until the vehicle backs away, then continues down. If an open command is received, the arm returns to the up position.

#### d. Safety/Reverse Only Function

- o Turn the **OSC** & **ONE-PASS** dip-switches **OFF**.
- o **Auto close timer** setup is required for this option.

#### Detector Setting:

On the **PRIME-VD1** or **PRIME-VD2** detector, configures the output as **Normally Closed (N.C.)**. (follow detector manual for this process)

### 2. EXIT Loop Setup

Install a **PRIME-VD1** or **PRIME-VD2** plug-in loop detector in the **Exit Loop** slot of the **LPR-2** rack.

#### Detector Setting:

On the **PRIME-VD1** or **PRIME-VD1** detector, configures the output as **Normally Open (N.O.)**. (follow detector manual for this process)

### 3. Access Control Device Wiring

Connect the access control device to the **COMMON** and **OPEN** terminal screws on the control board.

### 4. (Optional) Arming Loop Setup

To use an arming loop with the access control device:

a. Install a **PRIME-VD1** or **PRIME-VD2** plug-in loop detector in the **Phantom Loop** slot of the **LPR-2** rack.

b. On the detector, configures the output as **Normally Open (N.O.)**. (follow detector manual for this process)

c. Enable the Arming Loop:


- o Access the **LCD Settings Menu**.
- o Find and **enable the ARMING loop** setting.

#### Note:

Once enabled, the control board will only initiate an open cycle if a command from the access control device is received **while a vehicle is detected** by the arming loop. If no vehicle is detected, access control commands will be ignored.

**NOTE:** The input logic of the **ALL-BLDC PRO** requires only **one down loop**, even if open devices are present on both sides of the barrier arm.

In an **entry** scenario, the board will **ignore an exit loop activation one time** after the down loop has detected a vehicle passing through.



# TICKET DISPENSER ENTRY LANE

## Ticket Dispenser Entry — Wiring and Board Configuration

### 1. Down Loop (Safety Loop) Setup

Install a **PRIME-VD1** or **PRIME-VD2** plug-in loop detector in the **Safety Loop** slot of the **LPR-2** rack.

#### Safety Input Modes:

The safety input can operate in two ways:

#### a. Down Loop Only Function (see note)

- Turn the **ONE-PASS** dip-switch **ON** & **OSC** **OFF**.

#### b. Down and Safety/Reverse Function

- Turn the **OSC** dip-switch **ON** & **ONE-PASS** **OFF**.

#### c. Down and Pause Function

- Turn the **OSC** & **ONE-PASS** dip-switches **ON**.
- If the loop is activated while the arm is moving down, the arm will pause and wait for the vehicle to back away before resuming the down cycle. If an open command is received, the arm will return to the up position.

#### d. Safety/Reverse Only Function

- Turn the **OSC** & **ONE-PASS** dip-switches **OFF**.
- Auto close timer** setup is required for this option.

### Detector Setting:

On the **PRIME-VD1** or **PRIME-VD2** detector, configures the output as **Normally Closed (N.C.)**. (follow detector manual for this process)

### 2. Ticket Dispenser Device Wiring

Connect the ticket dispenser device to the **COMMON** and **OPEN** terminal screws on the control board (**N.O. CONTACT**).

### 3. Ticket Dispenser Arming Loop Setup

To use an arming loop with ticket dispenser device:

a. Install a **PRIME-VD1** or **PRIME-VD2** plug-in loop detector in the **Phantom Loop** slot of the **LPR-2** rack.

b. On the detector, configures the output as **Normally Open (N.O.)**. (follow detector manual for this process)


c. Enable the Arming Loop:

- Access the **LCD Settings Menu**.
- Find and **enable the ARMING loop** setting.
- See LCD display instructions page for more details .

### Note:

Once arming loop is enabled, the control board will only initiate an open cycle if a command from the access control device is received **while a vehicle is detected** by the arming loop. If no vehicle is detected, access control commands will be ignored.

**Important:** When Down Loop is configured as Down Loop only, a Down Loop activation while arm is traveling down, will not interrupt the down/close cycle. The arm will continue to complete the down/close cycle.



# AMS (ACCESS MANAGEMENT SEQUENCING) CONFIGURATION "RELAY MODE"



## MAGNA Q BARRIER ARM OPERATOR BOARD

## BLDC PRO GATE OPERATOR BOARD

### Barrier and Gate Operator Wiring


- Run four wires from board to board.
- Connect according to the chart below.

ì ÉÍ È Ì Ñ Ì È È Ì	BLDC PRO GATE TERMINAL
AUX RELAY 1 COMMON	COMMON ABOVE OPEN INPUT
AUX RELAY N.O.	OPEN INPUT
COMMON	AUX RELAY 1 COMMON
AUX INPUT 1	AUX RELAY 1 N.O.



See traffic lane configuration for loop detector and loop installation

See gate operator manual for detector and loop installation



## Access Management Sequencing (AMS) Overview

The Access Management Sequencing (AMS) is designed to manage and control vehicle traffic flow at facilities such as apartment complexes, businesses, and parking lots. It uses a **fast-operating barrier arm** alongside a **slower-moving security gate** to effectively regulate access.

The **barrier arm operator** quickly raises the arm to allow authorized vehicles through and immediately lowers it afterward to prevent tailgating or unauthorized entry. The **security gate operator** moves slower, providing an additional layer of access control.

Access control devices (e.g., card readers or keypads) connect to the **barrier arm operator**, which then sends open commands to the **gate operator**. The gate operator, in turn, sends a signal back once it reaches the open limit.

## Setting Up the Barrier Arm and Gate Operators for AMS Mode

### Barrier Arm Operator Setup

1. On the operator's LCD screen, navigate to **Settings**.
2. Locate and **enable AMS Mode (RELAY)**.

- When AMS RELAY Mode is active:
  - The barrier arm operator will send an **open command** to the gate using **Aux Relay 1** after receiving a valid signal from an access control device.
  - The barrier arm will **wait for the gate's open limit signal** (received via **Aux Input 1**) before raising the arm to allow vehicle passage.

### Gate Operator Setup (BLDC PRO Board)


1. On the gate operator's LCD screen, navigate to **Aux Relay Settings** and press **OK**.
2. Select the **Opened Signal** option.
  - This will configure the gate operator to send an **open limit signal** back to the barrier arm operator using its **Aux Relay 1**.

**Note:** For detailed instructions on navigating the LCD display, refer to the LCD Display section.

# AMS (ACCESS MANAGEMENT SEQUENCING) CONFIGURATION “DATA MODE”

MAGNA Q BARRIER ARM OPERATOR BOARD

BLDC PRO GATE OPERATOR BOARD



## Access Management Sequencing (AMS) Overview

The Access Management Sequencing (AMS) is designed to manage and control vehicle traffic flow at facilities such as apartment complexes, businesses, and parking lots. It uses a **fast-operating barrier arm** alongside a **slower-moving security gate** to effectively regulate access.

The **barrier arm operator** quickly raises the arm to allow authorized vehicles through and immediately lowers it afterward to prevent tailgating or unauthorized entry. The **security gate operator** moves slower, providing an additional layer of access control.

Access control devices (e.g., card readers or keypads) connect to the **barrier arm operator**, which then sends open commands to the **gate operator**. The gate operator, in turn, sends a signal back once it reaches the open limit.

## Setting Up the Barrier Arm and Gate Operators for AMS Mode

### Barrier Arm Operator Setup

1. On the operator's LCD screen, navigate to **Settings**.
2. Locate and **enable AMS Mode (DATA)**.

- When AMS DATA Mode is active:
  - The barrier must be set to Wireless Communication. To do this, press and hold the UP button. While holding the UP button, press and release the RESET button. When Wireless Pairing appears on the LCD, release the UP button, then press and release the RESET button again.
  - Similar to the AMS relay mode, the barrier operator will provide an open command to the gate operator and wait for the reply when gate reaches open limit.

### Gate Operator Setup (BLDC PRO Board)

1. On the gate operator, set the Primary/Secondary communication to Wireless.
  - press and hold the UP button. While holding the UP button, press and release the RESET button. When Wireless Pairing appears on the LCD, release the UP button, then press and release the RESET button again.

# TRAP/SALLY PORT SETUP

1st MAGNA Q OPERATOR BOARD

2nd MAGNA Q OPERATOR BOARD

## Barrier Operator Wiring

- Run four wires from board to board.
- Connect according to the chart below.

1st MAGNA Q TERMINAL	2nd MAGNA Q TERMINAL
AUX RELAY 1 COMMON	COMMON ABOVE OPEN INPUT
AUX RELAY N.O.	OPEN INPUT
COMMON	AUX RELAY 1 COMMON
STOP INPUT	AUX RELAY 1 N.O.

See traffic lane configuration for loop detector and loop installation

Loop Setup: Set the **Down** loops to each operator. Plug the detectors on the **Safety/Reverse** output for (N.C.). Connect loop wires into assigned terminals.

See gate operator manual for detector and loop installation

Plug in optional **Arming** loop detector in the Phantom slot and configure the detector output for (N.O.). Connect loop wires into assigned terminal. In settings menu, enable the **ARMING LOOP** by setting it to ON.

(follow detectors manual for output configuration)

To install the optional Interlocking Loop in the center of the two barrier arm operators, give us a call for instructions.

## Trap (Sally Port) Overview

The trap function is designed to manage and control vehicle traffic flow at facilities such as apartment complexes, businesses, and parking lots. It is used to prevent tail gating allowing only one vehicle at a time.

### Access Control Connections:

#### 1st Barrier Arm Operator Setup

1. Connect the access control device to COMMON and OPEN input.
2. If an option for visitor's exit input is required, the AUXILIARY INPUT 1 can be used as OPEN-CMD.
  - Connect the second visitor's exit device to the COMMON and AUX INPUT 1
  - In settings, set AUXILIARY INPUT 1 to OPEN-CMD


### Setting Up Barrier Arm Operators for Trap (Sally port) Mode

#### 1st Barrier Arm Operator Setup

1. On the operator's LCD screen, navigate to **Settings**.
2. Scroll down to **AUXILIARY RELAY** and press **OK** button.
  - Select **AUX RELAY ONE** and press **OK**:
    - Scroll down to **PULSE ON CLOSE** option and press **OK**.

#### 2nd Barrier Arm Operator Setup


1. On the operator's LCD screen, navigate to **Settings**.
2. Scroll down to **AUXILIARY RELAY** and press **OK** button.
  - Select **AUX RELAY ONE** and press **OK**:
    - Scroll down to **CLOSED SIGNAL** option and press **OK**.



# LED STRIP AND EDGE SENSOR INSTALLATION

## Instructions for Assembling Arm

1. Locate the **arm connecting link extrusion tube** and the four (4) **button socket head bolts** provided.
2. The **main arm section** comes with the **inner tube connecting link** already secured by a bolt.
  - Remove this bolt and carefully slide the **inner tube** out from the arm section.
3. Align the **threaded holes** of the **inner tube** with the **connecting holes** on the two **arm pieces**.
4. Insert the provided **button socket head bolts** through the connecting holes and into the threaded holes of the inner tube.
5. Tighten all bolts securely to complete the assembly of the two arm sections.



## LED Strip Installation

1. **Slide the LED strip** into the bottom rail of the arm.  
*Tip: Apply a small amount of fluid (e.g., soapy water) to the strip to help it slide more easily.*
2. **Route the LED strip wire leads** through the **pre-installed grommet** on the operator cabinet (the one closest to the traffic lane).
3. **Inside the cabinet**, continue routing the wire leads to the **bottom left** of the control board.
4. **Connect the LED strip wires as follows:**
  - **Red wire** → Positive terminal of the **12VDC power supply**.
  - **White wire** → **MAGLOCK** terminal on **AUX Relay 2**.
  - **Yellow wire** → **SOLENOID** terminal on **AUX Relay 2**.
  - **Negative wire** from the **12VDC power supply**

→ **COMMON** terminal on **AUX Relay 2**.

5. **Plug in the 12VDC power supply** (provided with the LED strip) into the **auxiliary 120VAC outlet**.

**Note:** It's required to go into LCD settings to enable the relay LED function. See LCD settings for details.

## Safety Edge Sensor Installation

1. **After installing the LED strip**, slide the **safety edge sensor** into the bottom channel of the LED strip.
2. **Insert the 10K resistor plug** into the end of the sensor closest to the **tip of the arm**.
3. **Insert the wire harness plug** into the end closest to the **operator**. Route the wires into the cabinet, and continue routing inside the operator.
4. **Connect the safety edge sensor wires:**
  - One wire to **COMMON**.
  - One wire to **MON-CLOSE** terminals.

# AC POWER ELECTRICAL WIRING

## OPERATOR **MUST** BE PROPERLY GROUNDED!

### • Grounding Requirements:

All gate operators **must** be properly grounded to mitigate the risk of electrical damage caused by nearby lightning strikes or electrostatic discharge.

- Use a **single, continuous wire** for grounding. **DO NOT** splice or join multiple wires. If damaged, replace the ground wire with a new, unbroken length. **Never** use multiple wires for grounding.
- Verify local electrical codes for approved earth ground rod types and grounding procedures, as proper grounding is essential for lightning protection of the control board.


### Power Wiring Requirements:

- Use **UL-listed conduit** for enclosing power wiring to ensure compliance with safety standards.
- This barrier arm operator support **120VAC or 208/240VAC single-phase power**. Set the voltage selector switch on the EMI board according to the chosen voltage. Refer to the table for proper incoming power wiring.
- Each operator must be powered by a **dedicated 20A minimum circuit** to ensure adequate power supply.

MAGNA Q	VOLTAGE	
	120VAC	240VAC
<b>CURRENT DRAW</b>	2.5AMPS	1.5AMPS
WIRE SIZE	MAX WIRE RUN IN FEET	
	120VAC	240VAC
<b>#14 WIRE</b>	180	360
<b>#12 WIRE</b>	280	560
<b>#10 WIRE</b>	450	900

Refer to the operator current draw and wire run tables above to accurately determine the appropriate wire gauge for the power run. Proper wire sizing is critical to minimizing voltage drop and ensuring reliable operation.

**IMPORTANT:** Due to the dual voltage configuration (120VAC/208/240VAC single-phase), the neutral connection of the receptacle is electrically independent from the neutral conductor of the EMI board. When operating at **120VAC**, the white wire connected to the receptacle neutral **must** be electrically bonded to the EMI board neutral. However, **when operating at 208/240VAC, this white wire must remain disconnected.** Failure to do so may result in damage to devices connected to the receptacle.



**NOTE:** When supplying **208/240V** to the operator, ensure that the **voltage selector switch** is set to **230V** to prevent operational issues or potential damage.


**CAUTION:** Before wiring high voltage, turn off the breaker to prevent electrical hazards.

Power Connection	120 VAC 50/60Hz	208/240 VAC 50/60Hz Single
LINE 1	120V HOT	208/240V LINE 1
LINE 2	120V NEUTRAL	208/240V LINE 2
GND	GROUND	GROUND

# DIP SWITCH FUNCTIONS



**NOTE:** IF ANY CHANGES ARE MADE TO THE DIP-SWITCHES, PRESS THE **MAIN RESET** BUTTON TO RECOGNIZE THE CHANGES.



## TIMER

Switch **ON** activates the automatic closing timer.  
*Note: down loop overrides timer. See page 21 for details.*

## RADIO

Switch **ON** allows the radio receiver to override the automatic close timer.  
*See page 21 for details.*

## OSC

Switch **ON** enables the down/safety loop to perform two distinct functions:

1. Once a vehicle clears the loop it lowers the arm when it is in the fully raised position.
2. If the arm is actively lowering, the loop will quickly stop and raise the arm.

**Note:** The **1-PASS** switch must be **OFF** for the OSC feature to function.

## FAIL SC/SF (Fail-Safe / Fail-Secure)

- **ON (Fail-Safe):** During power failure, the system monitors battery voltage to ensure the barrier arm opens before full battery depletion.
- **OFF (Fail-Secure):** During power failure, the barrier arm will continue operating until battery is low, then it will lock in the closed position.

## 1-PASS

Switch **ON** allows the arm to raise **UP (open)** and stay up until a vehicle passes over the **DOWN/SAFETY** loop. Once the vehicle clears the loop and the arm is fully raised, it will then lower (close).

## SECONDARY

Used in dual barrier arm setups.

- Switch should be **ON** only for the **secondary operator**.
- All other DIP switches must be **OFF**, except for **OPEN L/R**.
- On the **primary operator**, the **SECONDARY** switch should be **OFF**.

## AUTO OPEN

Automatically opens the barrier arm during a power outage. This feature is typically required by fire departments in specific areas.

- Set this switch to **ON** if auto-open is desired.
- There is a **40-second delay** between power loss and arm raising.

## OPEN L/R (Left/Right Opening)

- Switch **ON**: Right-hand arm opening
- Switch **OFF**: Left-hand arm opening

# AUTO CLOSE TIME SETTING & RADIO RECEIVER WIRING

## AUTO CLOSE TIMER SETTINGS

### TIMER

- **ON:** Activates the automatic close timer. The barrier arm will automatically close after a set duration, adjustable from **1 to 120 seconds (2 minutes)**. Note: If the down loop is enabled, a down loop activation will override the timer.
- **OFF:** Disables the automatic close timer. Barrier arm operation will require manual input: **press the button to open**, and **press again to close**. Down loop will also close the arm.

To set the desired auto-close duration, use the control panel up/down buttons to select the time. Once the desired seconds are displayed, press the **OK** button to save the setting.

### RADIO

- **ON:** Enables the radio receiver to override the automatic close timer. This allows the transmitter to close the arm before the auto-close timer elapses.

### TIMER & RADIO dip-switches



TIMER quick access button

## Radio Receiver Wiring Instructions

### Receiver Types

There are two types of radio receivers:

- **3-Wire Receivers**
- **4-Wire Receivers**

### 3-Wire Receiver Installation

#### 1. Connections:

- o **+12/24VDC:** Connect to the positive power input.
- o **RADIO:** Connect to the relay output.
- o **COMMON:** Connect to the shared ground/common terminal.

#### 2. Typical Terminal Assignments:

- o **Terminal 3:** +12/24VDC
  - o **Terminal 2:** Relay output
  - o **Terminal 1:** Common (shared ground)
- Note: Always refer to the receiver's installation manual to verify terminal assignments.*

#### 3. Voltage Selection:

- o Use the voltage selector jumper located at the top left corner of the control board to match the receiver's required voltage.


### 4-Wire Receiver Installation

#### 1. Connections:

- o **+12/24VDC:** Connect the positive power wire.
- o **RADIO:** Connect one of the relay contact wires.
- o **COMMON:** Connect both the second relay contact wire and the power negative wire.

#### 2. Voltage Selection:

- o Use the voltage selector jumper located at the top left corner of the control board to match the receiver's required voltage.



# ELECTRONIC REVERSING DEVICE (ERD) ADJUSTMENT

## Electronic Reversing Device (ERD) Adjustment

ALL-O-MATIC ALL-BLDC PRO control boards are equipped with an Electronic Reversing Device (ERD), which causes the barrier arm to reverse direction upon contact with an obstruction.

### Factory Settings

- **Default ERD Force:** 50%

### Adjustment Guidelines

- **If the arm reverses without obstruction:** The ERD force is too low.
- **If the arm does not reverse upon obstruction:** The ERD force is too high.

### Adjustment Procedure


#### 1. Accessing ERD Settings:

- o Use the quick-access **OPEN ERD** or **CLOSE ERD** buttons to enter the respective adjustment menu without navigating through the full menu.

#### 2. Adjusting ERD Force:

- o Press and release the corresponding ERD button.
- o The ERD adjustment will appear on the LCD display.
- o Use the **DOWN** button to decrease the force if arm does not stop and reverse upon contact with an obstruction.
- o After the arm reverses at a specific force setting, increase it by 15% to ensure reliable operation.

§ *Example:* If the barrier arm reverses at 20%, set the ERD force to 35%.



# PRIMARY/SECONDARY CONNECTION

## Primary/Secondary (P/S) Communication Setup

The ALL-O-MATIC BLDC PRO controller supports **wireless** and **hard-wired** Primary/Secondary communication. Accessories may be connected to **either** operator.

### Preliminary Steps

1. **Individually adjust the ERDs and limit switches on each operator** as standalone machines. (Refer to the ERD and limit switch adjustment pages for details.)
2. Set the **SECONDARY DIP switch** to ON on the **secondary controller**.
3. Press the **RESET** button on the **secondary controller**.

### Wireless Setup

1. On the **first unit**, press and hold the **UP** button. While holding **UP**, press and release **RESET** (do **not** release **UP** yet).  
→ LCD will display a message to **setup the other unit**, then show **default channel 1**.  
→ Release **UP**.
2. Repeat **step 1** on the **second unit**.
  - o Confirm that **both displays show the same channel**.
  - o Ensure the **SECONDARY DIP switch** is

ON on the secondary operator.

3. When both units display the **same channel** and correct DIP settings, they will automatically **link up** and the **P/S LINK LED** will turn **ON**.


**NOTE:** If multiple operator sets are in use with wireless communication and are within range of each other, each set must run on different channels. For instructions on how to change channels, see display menu settings pages.

### Hard-Wired Setup


1. On the **first unit**, press and hold the **DOWN** button. While holding **DOWN**, press and release **RESET** (do **not** release **DOWN** yet).  
→ LCD will display **WIRED MODE**.
2. Repeat **step 1** on the **second unit**.
  - o Confirm that DIP settings and preliminary adjustments are complete.
3. Wire the two operators **per the diagram**, ensuring:
  - o **DATA+ to DATA+**
  - o **DATA- to DATA-**  
→ Once connected, the units will **link up** and the **P/S LINK LED** will turn **ON**.

## PRIMARY CONTROLLER

## SECONDARY CONTROLLER



# PROGRAMMABLE RELAY



## ENTERING THE LCD DISPLAY MENU

1. **Wake the Display:**  
Press the OK button twice to wake up the screen.
2. **Enter English Menu:**  
When the welcome message appears, press the < (LEFT) button to access the English menu.
3. **Access Settings:**  
Use the UP or DOWN buttons to scroll through the options. When the cursor is on SETTINGS, press OK.
4. **Available Settings:**  
Within SETTINGS, you'll find options such as:
  - o AUXILIARY RELAY
  - o LEAF DELAY
5. **Navigation Tips:**
  - o Use the UP or DOWN to scroll
  - o Use the < (LEFT) button to return to the previous menu

## MAGNA Q – Auxiliary Relay Configuration

The MAGNA Q system includes **two programmable relays** (N.O. or N.C.), each with **four selectable configurations**.

### Accessing Auxiliary Relay Settings

1. From the **LCD display**, navigate to:
  - o **ENGLISH** menu →
  - o **SETTINGS** →
  - o Scroll down to **AUXILIARY RELAYS** →
  - o Press **OK**
2. You'll now see:
  - o **AUX RELAY ONE**
  - o **AUX RELAY TWO**
3. Select the desired relay and press the **OK** button to configure it.

### Relay Configuration Options

Each relay can be set to one of the following options:

**GATE OPEN COMMAND (Relay One Only)** see AMS page for wiring.

- Used to send an OPEN command to a gate operator. Run two wires from AUX Relay 1 COMMON and N.O. contacts to gate operator open command input.

- **AMS** (Access Management Sequencing) mode is to manage the access opening sequence of a gate and barrier arm operator combination

### LSI SIGNAL (Relay Two Only)

- Toggles the **RED/GREEN LED Strip Indicator Accessory while moving**
- Turns on RED LED in closed position and GREEN LED in fully opened position.

### MOVING SIGNAL (Relay one or two)

- Activates the relay **whenever the Arm is in motion**
- Ideal for motion-based signaling or alerts

### OPENED SIGNAL (Relay One or Two)

- Activates the relay **when the Arm is fully raised**
- Useful for notifying the end user of the arm's open status
- It could also be for LED strip if flashing lights isn't desirable. The strip will turn green only when it's on open limit. Any other position it will be red.

### CLOSED SIGNAL (Relay One or Two)


- Activates the relay **when the Arm is fully lowered**
- Useful for indicating the arm is securely closed

### PULSE ON CLOSE (Relay One only)

- Pulses the relay for one second when Arm reaches Closed limit. (Used for the trap/Sally port setup)

# MONITORED ENTRAPMENT PROTECTION DEVICE WIRING


## OVERHEAD VIEW OF DRIVEWAY



## WIRING ENTRAPMENT DEVICE TO DC BOARD


### WIRING DEVICE ACROSS DRIVEWAY / CLOSING DIRECTION (MON\_CLOSE)

WIRING THE AOM-RED-EYE (NOT INCLUDED WITH OPERATOR) TO THE CIRCUIT BOARD



### WIRING DEVICE FOR OPENING DIRECTION (MON\_OPEN)

WIRING THE AOM-RED-EYE (NOT INCLUDED WITH OPERATOR) TO THE CIRCUIT BOARD




ALL-BLDC PRO offers the 10K termination alternate option. Connect 10K sensor contacts to COMMON and MON-OPEN or MON-CLOSE as shown below.

Close contact edge with 10K termination


Open contact edge with 10K termination

**Additionally,** AUX INPUT 1 and 2 can be used to wire additional entrapment protection devices (10K or N.C. termination). For N.C. devices, power must be connected to MON +24VDC. For 10K devices power could be connected to the constant +12VDC or +24VDC if it requires power. See LCD display page for details of programming inputs.



# 3RD PARTY MONITORED ENTRAPMENT PROTECTION DEVICE CONNECTIONS

- There are 2 types of sensors that can be connected to the operator for UL 325 monitored entrapment compliance: non-contact sensors (photo eye) and contact sensors (edge sensors).
- Monitored entrapment protection devices use 4 wires to connect to the board. From the device, connect the **RELAY COMMON** to the board **COMMON** and the **NORMALLY CLOSED** relay contact to the assigned **MON\_OPEN** or **MON\_CLOSE** input. **MON +24VDC** and **COMMON** must be used to power these devices and properly monitor them.
- **IMPORTANT:** ALL-BLDC PRO can also work with 10K termination devices. See bottom of previous page for wiring details.
- **NOTE:** The power to the **MON +24VDC** terminal will be off when the arm is at rest (not moving). It will be normal to see the **MON\_OPEN** and **MON\_CLOSE** LEDs when the arm is closed. If the auto close timer is **OFF** it will do the same when the arm is at rest in the open position. Also, if no devices are connected both of these lights will stay ON.
- Please refer to the device manufacturer wiring instructions for details (on next page), making sure to follow the normally closed wiring directions. Some devices may work on monitoring interfaces other than normally closed.
- Should there be a need for more than 1 entrapment protection device for each direction, **AUX INPUT 1** and **AUX INPUT 2** could be used as MONITORED input expansion. See LCD display page for programming details.



## MON\_CLOSE (LED will indicate when an obstruction is detected or device is not present)

This input is only for the monitored entrapment protection device for the close direction. When the barrier arm is closing, it will open to the full open position if an obstruction is sensed and resets the automatic close timer. This input does nothing in the opening direction. If a device is not connected or sensed during power up, board assumes one is not required and will operate normal (it's normal to see LED on). If one is required and installed, board will monitor it once it's sensed.

## MON\_OPEN (LED will indicate when an obstruction is detected or device is not present)

This input is only for the monitored entrapment protection device for the open direction (only when required). If board does not sense a device connected, it will assume on is not required. When the barrier arm is opening, it will reverse for 2 seconds and stop if it senses an obstruction. This input does nothing in the closing direction. If a device is connected and the board detects a fault (MON\_FAULT LED will turn on). Once the obstruction is cleared, the barrier arm will operate normally. (it is normal to see the LED on if a device is not used/connected).

# ALTERNATE MONITORED ENTRAPMENT PROTECTION DEVICE WIRING

OMRON E3K-R10K4-NR		
SWITCH	CONTACT	BOARD TERMINAL
LIGHT ON	N.O.2	MON_CLOSE OR MON_OPEN
	C.2	COMMON
	24 TO 240 VAC	COMMON
	24 TO 240 VAC	MON_12/24VDC

EMX IRB-MON		
SWITCH	CONTACT	BOARD TERMINAL
SW1 - OFF	N.C.	MON_CLOSE OR MON_OPEN
SW2 - OFF	COM	COMMON
SW3 - ON	POWER/VRX	COMMON
SW4 - OFF	POWER/VRX	MON_12/24VDC

EMX IRB-325	
CONTACT	BOARD TERMINAL
N.C.	MON_CLOSE OR MON_OPEN
COM	COMMON
POWER	COMMON
POWER	MON_12/24VDC

EMX NIR-50-325	
WIRE	BOARD TERMINAL
BLACK	MON_CLOSE OR MON_OPEN
WHITE	COMMON
BLUE	COMMON
BROWN	MON_12/24VDC

EMX IRB-RET		
SWITCH	CONTACT	BOARD TERMINAL
SW1 - OFF	N.C.	MON_CLOSE OR MON_OPEN
SW2 - OFF	COM	COMMON
SW3 - OFF	POWER/VRX	COMMON
SW4 - ON	POWER/VRX	MON_12/24VDC

EMX WEL-200	
CONTACT	BOARD TERMINAL
RELAY CLOSE (NC) RELAY OPEN (NC)	MON_CLOSE MON_OPEN
RELAY CLOSE (COM) RELAY OPEN (COM)	COMMON COMMON
POWER	COMMON
POWER	MON_12/24VDC

MILLER EDGE RBAND 6 WIRES FOR 1 EDGE - 8 WIRES FOR 2 EDGES		
SWITCH	CONTACT	BOARD TERMINAL
SW 1 - ON	N/C N/C	MON_CLOSE MON_OPEN
SW 2 - ON	COM COM	COMMON COMMON
SW 3 - ON	COM A.TEST	COMMON MON_12/24VDC
SW 4 - ON	12/24 (+) AC/DC	24-VDC GROUND


MON\_CLOSE = PROTECTS ACROSS THE DRIVEWAY/CLOSING DIRECTION  
 MON\_OPEN = PROTECTS THE BARRIER ARM / OPENING DIRECTION

# ACCESSORY WIRING

The **ALL-BLDC PRO** controller has auxiliary **+12VDC** and **+24VDC** terminals that provide up to 750 mA on **+12VDC** and 750mA on **+24VDC** to power accessories. If the total current draw of the accessories exceeds the rated current for any of the +12VDC or +24VDC terminals, a separate power supply (transformer) is required.


**IMPORTANT:** From factory, we include wire jumpers on N.C. inputs. When installing a safety loop detector or a stop push button (**STOP** input), make sure to remove the wire jumper between the **COMMON** and **SAFETY LOOP** terminal for the safety detector and/or wire jumper between **STOP** and **COMMON** for a stop push button.

**AUX INPUT 1 AND AUX INPUT 2**, could be programmed to different functions. Depending on the function, the input can be N.O., N.C. or 10K termination for entrapment protection devices. See LCD display page for details on input function details.



# ACCESSORY WIRING (CONT.)

- A three button station and reset push button are integrated on the board to make limit and ERD adjustments easier.
- An external three button station may also be installed. See diagram below for wiring instructions.
- **NOTE:** STOP jumper must be removed if a three button station is installed.



## LED Strip Connection Using AUXILIARY Relay 2 (Lock Relay)

The **ALL-BLDC PRO** controller utilizes **AUXILIARY Relay 2** (Lock Relay) to control a **Red/Green LED Strip Indicator**. A dedicated power supply is required to operate the LED strip (included with the LED strip accessory).


### ⚡ Power Supply Connection:

1. Plug the LED strip power supply into the **auxiliary 120VAC outlet** on the control board.

### LED Strip Wiring Instructions:

2. **Power Supply and LED Strip**
  - o **Positive (striped) wire** from power supply → Connect to **red wire** of the LED strip harness.
  - o **Negative (solid black) wire** from power supply → Connect to **COMMON terminal** on **AUXILIARY Relay 2 (Lock Relay)**.
  - o **White wire** → Connect to the **MAGLOCK terminal**.
  - o **Yellow wire** → Connect to the **SOLENOID terminal**.

☑ Ensure all connections are secure and polarity is correct to avoid malfunction.



# SOLAR PANEL CONNECTION

The solar panel input requires a minimum 24VDC, 40-watt panel. The charging circuit supports up to 80 watts. With two (2) 14Ah, 12VDC batteries, a receiver, and two (2) monitored entrapment devices connected, the operator can provide approximately 100 cycles per day.

Be sure to connect solar panels to the **SOLAR** input. The onboard solar battery regulator features MPPT (Maximum Power Point Tracking) technology, offering greater efficiency than standard regulators.

For solar installations, upgrade the batteries based on usage demands. When the application requires more than 80 watts of solar power, an external charge controller regulator is necessary. See the next page for information on external solar system configuration.


For details on solar applications (e.g., panel size, battery capacity, etc.), please contact All-O-Matic.



MPPT ON BOARD  
REGULATOR  
90+% EFFICIENCY

CONNECT BATTERY  
HARNES TO BATTERY  
PLUG ON THE BOARD

CONNECT 24V PANEL  
INTO **SOLAR**  
INPUT ON CIRCUIT BOARD.





# EXTERNAL SOLAR SYSTEM INSTALLATION

When using an external solar package, connect the batteries directly to the BATTERY input. The batteries must be appropriately sized to meet the application requirements. See wiring diagram below.

For information on solar applications (e.g., panel sizing, battery capacity, etc.), please contact All-O-Matic.

**IMPORTANT:** If more than two solar panels are used, special wiring precautions are required to prevent damage to the batteries and/or the charge controller regulator. If 12VDC panels are used, they must be wired in series to achieve 24VDC. If 24VDC panels are used, they must be wired in parallel.



# LED DIAGNOSTICS

## P/S LINK

ON when primary/secondary communication is active. Will blink if dip-switch SECONDARY is ON and waiting to establish communication with primary.

## RADIO

ON when the RADIO input is activated (closed circuit to common).

## EXIT LOOP

ON when the EXIT input is activated (closed circuit to common).

## PHANTOM LOOP

ON when the PHANTOM LOOP input is activated (closed circuit to common).

## SAFETY LOOP

ON when the SAFETY LOOP input is activated (open circuit to common).

## FIRE ACCESS

ON when the FIRE ACCESS input is activated (closed circuit to common).

## MON\_CLOSE

ON when the MON\_CLOSE input is activated (open circuit to common) or when a device is not installed.

## MON\_OPEN

ON when the MON-OPEN input is activated (open circuit to common) or when a device is not installed.

## MON\_FAULT

ON when a fault has been detected on devices in MON-OPEN or MON-CLOSE inputs (if a device isn't working correctly or it isn't present).

## OPEN

ON when the OPEN inputs or OPEN push button are activated (closed circuit to common). It will be ON together with other inputs. See inputs page for more details.

## STOP

ON when the STOP input or STOP push button are activated (open circuit to common).

## CLOSE

ON when the CLOSE input or CLOSE push button are activated (closed circuit to common).

## ALARM

Turns on for 5 minutes (alarms also goes off) when the operator goes into shut down mode due to the arm

hitting an obstruction (ERD) twice before reaching fully closed position.

## TIMER

Blinks every 1/2 second when the timer is counting down to close automatically.

## MODE

Blinks **once** every two seconds when there is a problem with the motor **sensor** feedback. Blinks twice every **two seconds** when a **motor overload** is detected. Blinks **three** times every two seconds when the arm is **jammed**.

## OPENING

ON while the arm is opening.

## OPEN-LIMIT

ON while the limit cam is activating the open limit switch.

## CLOSING

ON while the arm is closing.

## CLOSE-LIMIT

ON while the limit cam is activating the close limit switch.

## AUX-IN 1

ON while AUX INPUT 1 is activated (closed circuit to common).

## AUX-IN 2

ON while AUX INPUT 2 is activated (closed circuit to common).

## FP\_DISABLE

ON when the Arm is not in place.

## AC/PWR ON

ON when AC power is on. It will also blink about every 1/2 second to indicate the main board fuse is blown.

## LOW-BATTERY

ON when the batteries are low, turned off or disconnected.

**TIPS:** When troubleshooting, it is important to note what lights are ON. It is very helpful to pay attention to the lights as they tell us what the board is doing and what inputs are active.

When calling ALL-O-MATIC for technical support please have the name of the lights that are ON in the control board. This will speed up the process to get the barrier arm operator up and running.



# AUX INPUT 1 & 2 PROGRAMMING

## AUX INPUT 1 & 2 Functions

### 1. EMERGENCY OPEN (Input 1 only factory default)

- Devices connected to this input will raise the Arm and override any MON-OPEN devices.
- Use a **Normally Open (N.O.)** contact.

### 1. EMERGENCY CLOSE (Input 2 only factory default)

- Devices connected to this input will lower the Arm and override any MON-CLOSE devices.
- Use a **Normally Open (N.O.)** contact.

### 2. OPEN-CMD

- Devices connected to this input will raise the Arm.
- Use a **Normally Open (N.O.)** contact from the device.

Note: If Aux Relay 1 is programmed for pulse on close, the relay will not pulse on close when an open command is received on this input. This would be used for visitors exit command.

### 3. CLOSE-CMD

- Devices connected to this input will lower the Arm.
- Use a **Normally Open (N.O.)** contact.

### 4. MON-OPEN

- Expands open-direction entrapment protection.

- Use a **Normally Closed (N.C.)** contact or a **10K termination** on the device.
- **IMPORTANT:** If using an N.C. contact, power the device from **MON +24VDC** for power.

### 5. MON-CLOSE

- Expands close-direction entrapment protection.
- Use a **Normally Closed (N.C.)** contact or a **10K termination** on the device.
- **IMPORTANT:** If using an N.C. contact, power the device from **MON +24VDC** for power.

### 6. STOP-CMD

- Devices connected to this input will stop the Arm.
- Use a **Normally Closed (N.C.)** contact.


### 7. GATE OPEN LIMIT (Input 1 only)

- Used for **AMS (Access Management System) mode**.
- Receives the **open limit** signal from the gate operator.

See LCD display menu pages for details on programming AUX INPUT 1 & 2.

Connect device relay contacts to these two terminals. Relay COMMON to board COMMON.  
RELAY N.O., N.C. or 10K to AUX INPUT 1. The relay contact depends on the function. See above for contact options.

Connect device relay contacts to these two terminals. Relay COMMON to board COMMON.  
RELAY N.O., N.C. or 10K to AUX INPUT 2. The relay contact depends on the function. See above for contact options.



# LCD SETTINGS AND DIAGNOSTICS

These instructions will take you through the ALL-BLDC PRO board LCD display menu.

Press OK a couple of times to wake the display until the options <ENG> and <ESP> appear. Select English with the left button or Spanish with the right button. After choosing a language, scroll to Settings or Diagnostics and press OK to enter. Use the up and down buttons to scroll, left and right to move the cursor, and press OK to save or select items.

## SETTINGS

### 1. TIME/DATE

- **1.1 TIME (XX:XX AM/PM)**
  1. Press **OK** when the cursor is on **TIME**.
  2. Use **Left/Right** to move between hour, minutes, and AM/PM.
  3. Use **Up/Down** to adjust values.
  4. Press **OK** to save.
- **1.2 DATE (MM/DD/YYYY)**
  1. Press **OK** when the cursor is on **DATE**.
  2. Use **Left/Right** to move between month, day, and year.
  3. Use **Up/Down** to adjust values.
  4. Press **OK** to save.

### 2. POWER

- **2.1 CURR. SENSE (PRGV)**

Adjusts how responsive the ERD is. Options are **Progressive** and **Threshold**, with **Threshold** being the most sensitive.
- **2.2 ERD**
  - o **OPEN ERD** – Adjusts opening ERD force (also accessible with the quick-access **OPEN ERD** button).
  - o **CLOSE ERD** – Adjusts closing ERD force (also accessible with the quick-access **CLOSE ERD** button).

### 3. 7-DAY TIMER

- **3.1 EVENTS (1–10)**

Each event allows you to program an **Action** with an **Activate Time**, a **Deactivate Time**, and specific **Days of the Week**. Up to 10 events can be programmed.

**Technician's Note:** Run a full gate cycle before programming events to ensure proper operation.

- **3.2 EVENT ACTION OPTIONS**
  - o **OPEN** – Opens arm and holds it open.
  - o **CLOSE** – Closes arm and holds it close.
  - o **AUX RELAY ONE**– Activates the auxiliary relay.
  - o **AUX RELAY TWO**– Activates the auxiliary relay.
- **3.3 PROGRAMMING AN EVENT (Step-by-Step)**
  - i. **Select an Event (1–10):**

Scroll to the desired event number and press **OK**.
  - ii. **Choose Action:** Use **Up/Down** to select **OPEN**, **CLOSE**, or **AUX RELAY ONE** or **TWO**, then press

## OK.

### iii. Set Activate Time:

1. Cursor appears on the hour field.
2. Use **Left/Right** to move between hours, minutes, and AM/PM.
3. Use **Up/Down** to adjust values.
4. Press **OK** to confirm.

### iv. Set Deactivate Time:

1. Follow the same process as above for the deactivate time.
2. Press **OK** to confirm.

### v. Enable Days:

1. Scroll through days of the week (Mon → Sun).
2. Toggle each day **ON** or **OFF** using **Right Button**.
3. After setting all days to the desired state, press **OK** to confirm.

### vi. Save Event:

Once all steps are completed, the event is saved and ready to run.

## 4. LEAF DELAY

- **4.1 DELAY TYPE**

Select whether the delay applies to **OPEN** or **CLOSE**. This function is mainly used for arms that overlap.
- **4.2 DELAY TIME (00.0 SEC)**

Set the delay duration in seconds. Use **Up/Down** to adjust the value and press **OK** to confirm.

## 5. ARMING LOOP (Phantom Loop) (Used to work with the access control device)

- **5.1 ARMING LOOP ON/OFF**

Enable or disable the ARMING LOOP. Set to **ON** to enable, or **OFF** to disable it.

**Note:** When enabled, an open command will only be accepted while the arming loop is detecting a vehicle.

## 6. PRE-WARN ALARM

(Uses the built-in audible alarm to warn before the arm starts moving.)

- **6.1 ALARM ON/OFF**

Enable or disable the alarm. Set to **ON** to activate, or **OFF** to deactivate.
- **6.2 DELAY TIME (00.0 SEC)**

Adjust the number of seconds the alarm sounds before arm movement. Range: **0–12 seconds**. Use **Up/Down** to adjust the value, then press **OK** to confirm.

# LCD SETTINGS AND DIAGNOSTICS (CONT.)

## 7. AMS MODE

(Access Management Sequencing setup)

- **7.1 Modes** (use the UP button to select mode)
  1. **OFF** (default)
  2. **RELAY** (Aux Relay 1 will be used to send an open command to a gate operator)
  3. **DATA** (uses RS-485 to communicate with the gate operator)

**Note:** For the data mode to work, both gate and barrier arm operators must be set to Wireless communication (even if it's a single machine). See Primary/Secondary page for details.

## 8. AMS FP BYPASS

(Used to select what to do in case arm breakaway)

- **OPTIONS** (use UP button to select)
  - **PULSE OPEN** (send a open pulse to gate when an open input signal is received)
  - **HOLD OPEN** (with this option, gate will be held open while the arm is in breakaway state)

## 9. AUXILIARY RELAY

(Options for relay activation.)

### 9.1 RELAY MODES

Select one of the following functions for the auxiliary relay: (an \* will be displayed to the right of selected mode.)

1. **OFF (INACTIVE)\*** – Default setting; relay is disabled.
2. **GATE OPEN CMD** (Relay one only) – Used for AMS relay mode to send a command to the gate.
3. **LSI Signal** (Relay two only) – Used to drive LED strip. Solid Red in down position, toggle red/green while moving and solid green in up position.
4. **MOVING SIGNAL** – Activates while the arm is moving.
5. **OPENED SIGNAL** – Activates when the arm is fully up position.
6. **CLOSED SIGNAL** – Activates when the arm is fully down position.
7. **PULSE ON CLOSE** (Relay one only) – Used for trap/sally port function to send an open command to the second barrier.

## 10. AUXILIARY INPUT

(Input 1 defaults to **EMERGENCY OPEN**, and Input 2 defaults to **EMERGENCY CLOSE**.) See auxiliary input page for more details.

### 10.1 INPUT MODES (1–2)

Each auxiliary input can be configured to one of the following functions: (an \* will be displayed to the right of selected mode.)

1. **EMERGENCY OPEN / CLOSE\*** – Overrides monitored inputs and forces the arm to fully open or close.
2. **OPEN\_CMD** – Functions the same as a standard open input. Except in a trap/sally port function it serves as visitor exit input to allow a

visitor to exit after first arm & not open second arm.

3. **CLOSE\_CMD** – Functions the same as a standard close input.
4. **MON-OPEN** – Expansion of the monitored open input.
5. **MON-CLOSE** – Expansion of the monitored close input.
6. **STOP\_CMD** – Functions the same as the STOP input.
7. **GATE OPEN LIMIT** (Input 1 only) – Used as input to receive the gate (AMS relay mode) open limit signal.

## 11. SERVICE CYCLE

(Provides a planned service reminder based on run cycles.)

### 11.1 SETTINGS

1. Scroll to **SERVICE CYCLE** in the menu and press **OK**.
2. Program the number of cycles the arm should run before the next preventive maintenance service call.
3. Press **OK** to confirm.

### 11.2 FUNCTION

- The control board begins counting down from the programmed number.
- When the count reaches zero, the board will beep to alert the end user that it's time to schedule service.
- The cycle count can be reset by a technician in the **Diagnostics** → **Cycle Count** menu.

### 11.3 COUNT (00000)

1. Use **Left/Right** to move the cursor between tens, hundreds, thousands, and ten-thousands positions.
2. Use **Up/Down** to adjust the value.
3. Press **OK** to confirm.

## 12. AUTO CLOSE TIMER

(See timer page for more details on this)

### 12.1 SETTINGS

1. Scroll to **AUTO CLOSE TIMER** in the menu and press **OK**, or press the quick-access **TIMER** button.
2. Use **Up/Down** to set the delay (0–120 seconds).
3. Press **OK** to confirm.

## 13. VEHICLE MEMORY

(This determines whether the arm waits for a second vehicle to clear the down loop)

### 13.1 VEHICLE MEM ON/OFF

- 01-Using UP button toggle between ON/OFF.
3. Press **OK** to confirm.

# LCD SETTINGS AND DIAGNOSTICS (CONT.)

## 14. SETTINGS CHG LOG

(Keeps a record of the last three times settings were changed)

- **14.1 ENTRIES** (use up/down buttons to scroll)
  - 01-03. SETTINGS CHG – XX/XX/XX 00:00 AM**  
Shows the saved date and time of the changes.
  3. Press **OK** to exit.

## 15. FIRMWARE UPDATE

(used to update firmware in the field)

- **15.1 UPDATE PROCESS**
  1. Obtain the firmware **ZIP** file from AOM (provided via email).
  2. Copy the file to a thumb drive formatted to **FAT, FAT16, or FAT32**.
  3. Plug the thumb drive into the board's **USB port**.
  4. Follow on-screen instructions to complete the update.

**16. WIRELESS SETUP** (For wireless primary/secondary setups, use a unique channel when other systems are nearby. There are 64 available channels.)

- **16.1 WIRELESS CHANNEL**
  1. Ensure both operators in a pair are set to the **same channel**.
  2. If other systems are nearby, select a different channel to avoid conflict.

## 17. SET TO DEFAULT

(Restore individual settings, or all settings, to factory defaults.)

- **17.1 OPTIONS**
  1. **DEFAULT ALL** – Restores all settings.
  2. **DEFAULT POWER** – Restores power settings.
  3. **DEFAULT 7/D TMR** – Restores 7-Day Timer settings.
  4. **DEFAULT LEAF DLY** – Restores leaf delay settings.
  5. **DEFAULT ARMING** – Restores arming loop settings.
  6. **DEFAULT PRE ALRM** – Restores pre-warn alarm settings.
  7. **DEFAULT AMS MODE** – Restores ams mode settings.
  8. **DEF AMS FP BYPASS** – Restores ams fp bypass settings.
  9. **DEFAULT AUX RLY** – Restores auxiliary relay settings.
  10. **DEFAULT AUX INS** – Restores auxiliary input settings.
  11. **DEFAULT SVC CYC** – Restores service cycle settings.
  12. **DEFAULT AUTO CLS** – Restores auto close

timer settings.

**13. DEFAULT WIRELESS** – Restores wireless setup settings.

**14. DEF VEHICLE MEM** – Restores vehicle memory settings.

## DIAGNOSTICS

### 1. BARRIER STATUS

Displays whether the arm is **CLOSED, OPENED, or STOPPED**.

### 2. COMMUNICATION

(Displays the current communication mode.)

#### 1. Wireless CH XX

#### 2. Wired

### 3. CPU TEMPERATURE

1. Displays CPU temperature.

### 4. 7/D TMR STATUS

Displays if the arm is being held open or if the relay is active by the 7-Day Timer.

### 5. METER

(Provides real-time voltage readings.)

1. **BATT VOLTAGE** – Displays battery voltage.

2. **LINE IN VOLTAGE** – Displays line input voltage.

### 6. MOTOR

(Displays motor speed and arm travel as a percentage.)

#### • 6.1 MOTOR SPEED

Shows the current operating speed of the motor.

#### • 6.2 TRAVEL

Displays the percentage of arm travel completed.

### 7. LAST EVENT

(Displays the most recent event recorded by the system.)

#### • 7.1 EVENT NAME

Example: **50. (LAST LOGGED EVENT NAME)**

#### • 7.2 EVENT DATE & TIME

Example: **XX/XX/XX 00:00 PM**

### 8. EVENT LOG

(Stores up to 50 special events.)

#### • 8.1 LOGGED EVENTS

Displays entries **1–50** in the event log.

### 9. CYCLE/VEHICLE COUNT

(Displays the unit's cycle and vehicle counts, including service cycles if programmed.)

#### • 9.1 LIFE CYCLES

Total number of cycles/vehicle since installation.

#### • 9.2 MONTH CYCLES

Total cycles/vehicle for the current month.

#### • 9.3 DAY CYCLES

Total cycles/vehicle for the current day.

#### • 9.4 SERVICE CYCLES

count down programmed service cycle count. Presents an option to reset when 0 count reached.

# LCD SETTINGS AND DIAGNOSTICS (CONT.)

## 10. EXPORT TO USB

(Allows settings and diagnostic data to be exported for review on a smartphone or PC. The thumb drive must be formatted to FAT, FAT16, or FAT32.)

### 10.1 EXPORT PROCESS

Insert a formatted thumb drive into the USB port to export data and follow the prompt.

## EVENT LOG – POSSIBLE FAULTS AND DEFINITIONS

(The event log records up to 50 events, including system faults. Review these entries during diagnostics to identify and correct issues.)

### General Notes:

1. Inputs that remain active for more than 5 minutes should be investigated. This may be intentional, but it could also indicate a phantom issue that intermittently holds the arm open or closed.
2. Logged inputs showing ON/OFF changes help diagnose the cause of arm malfunctions.
3. **P/S LINK OFF** and **P/S LINK ON** events indicate intermittent communication issues.
  - o For hard-wired systems, check communication cable connections.
  - o For wireless systems, check for possible sources of interference in the environment.

### FAULT DEFINITIONS

- **EXIT IN >5m** – Exit loop input active for more than 5 minutes.
- **SAFE IN >5m** – Safety loop input active for more than 5 minutes.
- **P/S LINK OFF** – Communication between Primary/Secondary operators lost.
- **P/S LINK ON** – Communication between Primary/Secondary operators established.
- **AC PWR OFF** – AC power lost.
- **AC PWR ON** – AC power detected.
- **BATTERY OFF** – Battery power lost.
- **FUSE BLOWN** – Motor fuse blown. Replace fuse on main board.
- **STOP FP ON** – FP DISABLE input activated, arm stopped. Check FP\_DISABLE sensor.
- **STOP FP OFF** – FP DISABLE input deactivated.
- **RADIO IN >5m** – Radio input active for more than 5 minutes.
- **EDGE IN ON** – Edge 10K input triggered.
- **CLOSE IN >5m** – Close input active for more than 5 minutes.
- **CLOSE ERD** – Close ERD tripped. Inspect arm and adjust ERD if necessary.
- **OPEN ERD** – Open ERD tripped. Inspect arm and adjust ERD if necessary.

- **PHANTOM >5m** – Phantom loop input active for more than 5 minutes.
- **AC VOLT LOW** – AC voltage drop detected. Inspect main power connections.
- **AC VOLT HIGH** – High AC voltage detected. Check power supply.
- **MOTOR OL** – Motor overload. Check arm hardware and operator capacity.
- **EEPROM ERROR** – Processor error. Replace board.
- **MON-OPEN FLT** – Fault on monitored open input. Check entrapment device alignment/function.
- **MON-CLOSE FLT** – Fault on monitored close input. Check entrapment device alignment/function.
- **FIRE IN >5m** – Fire access input active for more than 5 minutes.
- **OPEN IN >5m** – Open input active for more than 5 minutes.
- **AUX1 OPEN >5m** – Aux1 Open input active for more than 5 minutes.
- **AUX2 OPEN >5m** – Aux2 Open input active for more than 5 minutes.
- **AUX1 CLOS >5m** – Aux1 Close input active for more than 5 minutes.
- **AUX2 CLOS >5m** – Aux2 Close input active for more than 5 minutes.
- **AUX1 PARTIAL OPEN >5m** – Aux1 Partial Open input active for more than 5 minutes.
- **AUX2 PARTIAL OPEN >5m** – Aux2 Partial Open input active for more than 5 minutes.
- **AUX1 FORCE OPEN >5m** – Aux1 Emergency Open input active for more than 5 minutes.
- **AUX2 FORCE CLOSE >5m** – Aux2 Emergency Close input active for more than 5 minutes.
- **AUX1 STOP ON** – Aux1 STOP input activated, arm stopped.
- **AUX1 STOP OFF** – Aux1 STOP input deactivated.
- **AUX2 STOP ON** – Aux2 STOP input activated, arm stopped.
- **AUX2 STOP OFF** – Aux2 STOP input deactivated.
- **MOTOR SF** – Motor sensor fault. Check motor harness connections.
- **STOP-IN ON** – STOP input activated.
- **STOP-IN OFF** – STOP input deactivated.
- **LOCKED ROTOR** – Check motor mechanism.
- **ARM JAMMED** – Check arm.
- **CHANNEL CONFLICT** – Wireless interference. Change the schannel.

# MAGNA Q MANUAL RELEASE

## Procedure to Manually Raise or Lower the Arm:


1. Unplug the motor power harness from the board.
2. Pull out the blue spindle handle on the motor.
3. Turn the spindle to manually raise or lower the arm.
4. Once the arm is in the desired position, fold the spindle handle back in.
5. Reconnect the motor power harness to the board.

## SAFETY TIPS:

1. It's important to disconnect the motor power harness from the board. As it prevents the motor from spinning unintentionally.
2. Also, disconnecting the motor from the board it will be easier to turn the spindle.

## MANUAL OPERATION TIPS:

If possible to reach the arm as the spindle is being turned, the arm can move by grabbing it and forcing it in the desired direction. The arm will lock in place in the fully raised or lowered position.



# WARRANTY CARD

## MANUFACTURER'S LIMITED WARRANTY

**ALL-O-MATIC INC** warrants the MAGNA Q aluminum cabinet for a period of ten (10) years and electrical & mechanical components for a period of three (3) years. The above operator, within its warranty period, is to be free from defects in circuitry, motor, gearbox and workmanship. This warranty begins from the date of purchase to the original owner. Warrantor will repair or, at its option, replace any device which it finds to require service. This device must be sent to the warrantor at the consumer's expense to:

**ALL-O-MATIC INC.  
7658 HASKELL AVE.  
VAN NUYS, CA 91406**

The warrantor will return the repaired or replaced unit to the customer at the consumer's expense. Labor charges for dealer service or replacement are the responsibility of the owner. These warranties are in lieu of all other warranties either expressed or implied, and ALL-O-MATIC INC shall not be liable for consequential damage. All implied warranties of merchantability and or fitness for a particular purpose are hereby disclaimed and excluded. This limitation is not valid in jurisdictions which do not allow limitation of incidental or consequential damages or limitation of warranty periods. In order to obtain this policy, please complete the registration card and send it by mail within 30 days of purchasing from ALL-O-MATIC INC. or your installer. If product is not registered, only a one year warranty on all parts will be provided.

CUT HERE

### OWNERS REGISTRATION CARD (Owner of property where barrier arm operator is installed)

Customers Name \_\_\_\_\_ Phone \_\_\_\_\_

Address \_\_\_\_\_ City \_\_\_\_\_

State \_\_\_\_\_ Zip \_\_\_\_\_ E-MAIL: \_\_\_\_\_

Purchased from (Installation Co.) \_\_\_\_\_ Date \_\_\_\_\_

Address \_\_\_\_\_ City \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_

Phone \_\_\_\_\_ E-MAIL: \_\_\_\_\_

Model Number \_\_\_\_\_ Serial Number \_\_\_\_\_ - \_\_\_\_\_

**PLEASE RETURN THIS PORTION**

**ALL-O-MATIC GATE AND BARRIER ARM OPERATORS**

CUT HERE

# WARRANTY CARD

**This card must be mailed and filed for warranty to be valid**

**(Please retain this portion)**

## CUSTOMERS RECORD

Customer Name \_\_\_\_\_

Address \_\_\_\_\_

Purchased from (Installation Co.) \_\_\_\_\_ Date \_\_\_\_\_

Model Number \_\_\_\_\_ Serial Number \_\_\_\_\_ - \_\_\_\_\_

**Please retain this portion as a receipt for warranty for your own protection**

CUT HERE

PLACE  
STAMP  
HERE

**ALL-O-MATIC INC.  
7658 HASKELL AVE.  
VAN NUYS, CA 91406**



# ALL-O-MATIC®

MANUAL



SAFETY US/CA  
SÛRÉTÉ US/CA  
E543801

